



### Freedesk Desk Riser

Activates you and your body

Raises and lowers to 9 different levels

From sitting to standing fast and soundless

Simple to lower down and move around

Developed and designed in Sweden

Freedesk Desk Riser is designed to transform any surface from passive desktop to flexible sit-stand. With 9 different positions, you can adjust it to the level that works best for you. The slim lightweight design makes the Freedesk Desk Riser extremely portable, so you can move it around from room to room or between your home and workplace.

## Safety manual for proper usage of the Freedesk Desk Riser.

Read this safety manual page A, B and C before using this product.

Also see handling illustrations on page 1 and 2.

Keep this manual in a safe location for future reference.

In case of loosing this Manual or, in the event that Freedesk AB modifies the Manual it is possible to obtain a new copy at <http://us.thefreedesk.com>

Freedesk Ab retains the right to modify the Manual as it deems appropriate and that the consumer is charged with the knowledge of the contents of any modified Manual.




Figure 1.  
Desk Riser

### WARNING

- Serious damage to property, bodily injury, and even death can result from not following the below safety instructions
- Always use both hands, one on each side of the Desk Riser where there are built-in handles, when maneuvering the Desk Riser up and down. Using only one hand to operate the Desk Riser could make the Desk Riser fall. (Fig. 3).
- Put the Desk Riser on an existing table or other plain surface, that is at least 32\*21 inches/81\*53cm. Placing the Desk Riser on a surface that is smaller than this could result in the product legs falling off of the surface when in use. (Fig. 3).
- When using the built in handles, always use your fingertips in the dedicated handles (Fig. 6). Fingers placed under the Desk Riser when raising or lowering the Desk Riser could be pinched (Fig. 5).
- When transporting or storing the Desk Riser, make sure to engage the locking mechanism to keep the legs in place (Fig. 7). Transporting or storing the desk riser without engaging the locking mechanism could result in the legs extending and cause the Desk Riser to break.
- The maximum weight capacity of the Desk Riser is 10kg/22lbs. Overloading the work surface could cause the Desk Riser to break, void the warranty and cause injury.
- Do not sit, lean, or stand on the Desk Riser. (Fig. 8).
- Small children should never use the Desk Riser.
- Make sure the area underneath the Desk Riser is free and clear of objects at all times.
- Never use the Desk Riser for ironing.
- It is not possible to warn the consumer about every possible danger related to use of the Desk Riser and the consumer must use his or her own common sense and good judgment when using the Desk Riser.




Figure 2.  
Desk Riser overview



Figure 3.  
Top view of the Desk Riser




Figure 4.  
Desk Riser placed on a table.

Always use both hands, one on each built-in handle, when raising and lowering the work surface. Using only one hand could make the Desk Riser fall. Put the Desk Riser on an existing table or other plain surface, that is at least 32\*21 inches/ 81\*53cm. Placing the desk riser on a surface that is smaller than this could result in the Desk Riser legs falling off of the surface when in use.




Figure 5.






Figure 6.

When using the built in handles, always use your fingertips in the dedicated handles (Fig 6). Fingers placed under the desk riser when raising or lowering the work surface could be pinched (Fig 5).



ATTENTION: When transporting or storing the Desk Riser, make sure to engage the locking mechanism (Fig 7), to keep the legs in place. To access the locking device, slide the Desk Riser over the edge of the table or tilt slightly up (Fig 7). Do not turn the Desk Riser upside down or transport without locking the legs. Make sure to unlock the legs when adjusting the height of the work surface.

Figure 7. Showing placement of lock and how to use it.



Do not sit, lean, or stand on the Desk Riser. This product is not recommended for use by small children. If not used correctly, there is risk of pinching and injury. Make sure the area underneath the Desk Riser is free and clear of objects at all times.

Figure 8.




Figure 9.

The maximum weight capacity of the Desk Riser is 10kg / 22lbs. Overloading the work surface could cause the product to break, void the warranty and cause injury.




Figure 10.

Friendly tip for first time users of sit/stand products. Listen to your body when standing while working. Sit down if you experience any discomfort and allow yourself some time to get used to standing up while working.





Figure 11.

Figure 13. When the Desk Riser is unlocked, use both hands, one on each built-in handle. Lift the desk riser up to preferred level. IMPORTANT: The locking mechanism should be on the side closest to you when using the Desk Riser.

Tilt the work surface to engage and disengage the height adjustment mechanism (9 positions)




Figure 14 . When lowering the Desk Riser, use both hands, one on each built-in handle, slightly tilt the right side of the work surface up. IMPORTANT: The locking mechanism should be on the side closest to you when using the Desk Riser




Figure 15. Lower the Desk Riser to desired level.




Figure 16. When desired level is reached slightly tilt the right side of the work surface down.




Figure 17. In order to stand up and work, place the Desk Riser on a table.




Figure 18. When folded and locked, the Desk Riser can be lifted and moved around




Figure 19. The Desk Riser can be adjusted to nine different levels




Figure 20. When folded and locked, the Desk Riser can easily be stored.




Figure 21. When folded and locked, the Desk Riser can be stored.




Figure 22. When folded and locked, the Desk Riser can be stored standing up leaning on a wall or other support.




Figure 23. When folded and locked, the Desk Riser can be mounted on a wall if you have a firm support.